

Practical Applications of FactSage at VOEST Donawitz


Alexander Paul

voestalpine Stahl Donawitz GmbH www.voestalpine.com/stahldonawitz



Content

- Goal and motivation
- Facilities and aim of the secondary metallurgy treatment
- Calculations and comparisons
- Summary



2 | 15.12.2016 | Practical applications of FactSage at VOEST Donawitz


Goal and motivation

Goal:

The secondary metallurgy helps to reduce the NMI and modifies their composition.

Motivation:


The understanding of the thermodynamics of the secondary metallurgical treatment helps to fit the optimal operating parameters.



3 | 15.12.2016 | Practical applications of FactSage at VOEST Donawitz


Content

- Goal and motivation
- Facilities and aim of the secondary metallurgy treatment
- Calculations and comparisons
- Summary



4 | 15.12.2016 | Practical applications of FactSage at VOEST Donawitz

Flowchart: voestalpine Stahl Donawitz GmbH



5 26.06.2014 Practical applications of FactSage at VOEST Donawitz

Why ladle furnace?

Operating parameters:

- 65 t capacity
- 5 °C/min heating capacity
- Ladle lining based on AI_2O_3

Aim of the treatment:

- Regulation of temperature
- Si/Mn deoxidation
- Slag treatment
- Bubbling
- Modification of the NMI-composition
 - Agglomeration and segregation of NMI





voestalpine Stahl Donawitz GmbH Practical applications of FactSage at VOEST 15.12.2016 6 Donawitz

Why vacuum-(RH)-treatment?

Operating parameters:

- 1550-1600 °C
- 1 mbar
- 12-20 min

Aim of the treatment:

- Vacuum-carbon-deoxidation (C=0.5-0.7%)
- Reduction of O_{tot} (total oxygen content)
- Modification of the NMI-composition
- Agglomeration and segregation of NMI






voestalpine Stahl Donawitz GmbH Practical applications of FactSage at VOEST 15.12.2016 Donawitz

Modification of the NMI

 NMI composition is near the eutectic depression (Anorthite-Wollastonite-Tridymit)

NMI-Size:

As less as possible and small (<5 μm) NMI



voestalpine

voestalpine Stahl Donawitz GmbH

8 | 15.12.2016 | Practical applications of FactSage at VOEST Donawitz

Content

- Goal and motivation
- Facilities and aim of the secondary metallurgy treatment
- Calculations and comparisons
- Summary



Starting conditions variation 1

Parameters:

- pressure variation between 1 and 0.001 bar
- 1600°C
- O_{tot} = 120 ppm

Databases and Solutions

- FSstel
 - FSstel-Liqu
- FToxid
 - FToxid-SlagA
 - FToxid-bC2S
- FactPS
 - pure solids
 - gas


									_	_	
	-		-		_			-	-		

steel analyse									
С	Si Mn Cr Al Ca Mg'								
w%	w%	w%	w%	ppm	ppm	ppm			
0.53	1.60	0.65	0.65	15	1	0.5			

*accepted



Result variation 1



voestalpine Stahl Donawitz GmbH

Practical applications of FactSage at VOEST 15.12.2016 11 Donawitz

Starting condition variation 2

Parameters:

- variation of the O_{tot}-content between 120 and 5 ppm
- 1600°C
- 1 bar !!!

Databases und Solutions

- FSstel
 - FSstel-Liqu

FToxid

- FToxid-SlagA
- FToxid-bC2S
- FactPS
 - pure solids

steel analyse										
С	Si Mn Cr Al Ca I									
w%	w%	w%	w%	ppm	ppm	ppm				
0.53	1.60	0.65	0.65	15	1	0.5				


*accepted



voestalpine Stahl Donawitz GmbH

12 | 15.12.2016 | Practical applications of FactSage at VOEST Donawitz


Comparison of Variation 1 and 2



voestalpine Stahl Donawitz GmbH

Practical applications of FactSage at VOEST 15.12.2016 13 Donawitz


Results and comparison of the modification



voestalpine Stahl Donawitz GmbH

14 | 15.12.2016 | Practical applications of FactSage at VOEST Donawitz voestalpine

Results and comparison of the modification



15.12.2016 Donawitz

Starting conditions variation 3

Parameters:

- variation of the O_{tot}-content between 120 and 5 ppm
- 1600°C
- 1 bar !!!
- $a(AI_2O_3(S6))=0.03 \cong 0.015kg_{FF}/t_{steel}$ chemical refractory wear
- total refractory wear \cong 0.6 kg_{FF}/t_{steel}

Databases und Solutions

- FSstel
 - FSstel-Liqu
- FToxid
 - FToxid-SlagA
 - FToxid-bC2S
 - FactPS

pure solids


steel analyse										
С	Si Mn Cr Al Ca Mg*									
w%	w%	w%	w%	ppm	ppm	ppm				
0.53	1.60	0.65	0.65	15	1	0.5				

*accepted




voestalpine Stahl Donawitz GmbH

Results and comparison of the modification



17 | 15.12.2016 | Practical applications of FactSage at VOEST Donawitz


Devolution of the oxide phases



voestalpine Stahl Donawitz GmbH


Practical applications of FactSage at VOEST 15.12.2016 18 Donawitz

Devolution of the oxide phases



19 | 15.12.2016 | Practical applications of FactSage at VOEST Donawitz

Results and comparison of the NMI-mass






20 | 15.12.2016 | Practical applications of FactSage at VOEST Donawitz

EINEN SCHRITT VORAUS.

voestalpine

Relative weight lost



Content

- Goal and motivation
- Facilities and aim of the secondary metallurgy treatment
- Calculations and comparisons
- Summary



Summary

- The active oxygen content influences significantly the NMI modification.
- The variation of the system pressure leads to the desolution of the NMI below 0.21 bar (4.4 ppm O_{active}).
- The variation of the total oxygen content leads to the formation of 2CaOSiO₂ at O_{active} < 4.4 ppm (without refractories)</p>
- The influence of the refractory material can be described by fixing the activity of Corundum.
- At low active oxygen contents below 10 ppm, the fixing of the activity of Corundum lost it's validity.





Thank you!

Alexander Paul T. +43/50304/25-3147 alexander.paul@voestalpine.com



 voestalpine Stahl Donawitz GmbH

 24
 15.12.2016
 Practical applications of FactSage at VOEST

 Donawitz
 Donawitz